ABN 17 124 981 611

Unit 3, 34 Fallon Rd
Landsdale WA 6065
www.smssecurity.com.au
admin@smssecurity.com.au
(08) 9302 0000

Alarm Instructions

Arming

To arm the system wait till you see the green tick and hold down **5** until the keypad beeps. You can also arm using your **4 digit code**.

Disarming

To disarm enter your **4 digit code**.
If you ever make a mistake press **#** and start again.
To partially arm the system at night press **2** for one second.

Bypassing a Zone

Press ***
Press **1**
Type in the Zone you are having trouble with (ie. Zone 6 would be 06; Zone 12 would be 12)
Press **#**

Arm

Do this every time you leave and arrive back home

To change time: * 6 _ _ _ _ (Master Code) **Press 1** _ _ _ _ _ (24Hr Time) _ _ (Month) _ _ (Day) _ _ (Year) **#**

To change code: * 5 _ _ _ _ (Master Code) _ _ (User No.) _ _ _ _ (New Code) **Press #**

Enter user number according to which code to change. Master code is User 40. If client wants to add a new code and they have no other active codes then you would start at user 01. When entering user number must always be 2 digits. Always remember master code I User 40!!!

To check trouble condition:

Enter: ***2** and a number will then appear on the screen.

1 - System trouble. Press **1** again to determine the exact problem.

- If number **1** appears again the system has a low battery.
- If number **2** appears there is a problem with the bell circuit.
- If number **3** appears there is general system trouble.
- If number **4** appears there is a fault with a tamper input on a module *(e.g. expander).*
- If number **5** appears there is a problem communicating with a module on the system *(e.g. keypad, expander, anything which would connect to the com bus).*
- If number **6** appears there is a RF Jam Detected.
- If number **7** appears the PC5204 module has a low battery.
- If number **8** appears the PC5204 module has AC Fail.

2 – No AC to Panel (No Power)

3 – Telephone line trouble.

4 – Failure to communicate to monitoring station or client's mobile phone.

5 – Zone Fault. Press number **5** again to determine which zone has the fault.

6 – Zone Tamper. Press **6** again to determine which zone has the fault.

7 – Wireless Device Low Battery. Press **7** again to see which zones have low batteries

8 – Loss of Clock and Date.